



IMPORTANT:

Read all instructions carefully before attempting installation. If you do not understand these instructions, please consult your local distributor. Thoroughly inspect the fixture for any freight damage; freight damage should be reported to the delivery carrier.



WARNING:

Disconnect power during installation and before servicing. Wear gloves to prevent cuts/abrasions from sharp edges when removing from carton, handling, and maintaining this fixture.




SAFETY:


This fixture must be wired in accordance with the National Electric Code and applicable local codes or ordinances. All work should be performed by a qualified electrician. To insure personal safety, proper grounding is required (connect green fixture lead to supply ground).

MOUNTING:


Securely attach mounting brackets (2) to mounting surface (brackets can be surface, chain, or cable mounted). The VSL8 enclosure will engage the mounting brackets at any point along the fixture's length, except where there are latches. It is recommended that the distance between brackets equal 70 - 80% of the fixture's length.




Insert one side of the fixture into mounting brackets.



Push up on fixture and press in on the mounting bracket until the mounting bracket snaps into place.



Verify that the enclosure is fully supported before connecting to a power supply.



LUMINAIRE SUPPLY WIRING CONNECTIONS: (Use only approved connectors for all electrical connections.)

1. Luminaire supply power connects to Luminaire Disconnect Plug labelled as "BALLAST DISCONNECT" (typically yellow in color; see FIG-1).
2. Connect the Black fixture wire to the black supply wire (LINE).
3. Connect the White fixture wire to the white supply wire (NEUTRAL).
4. Connect the Green fixture wire to the supply ground wire.
5. Driver Voltage: This fixture is typically provided with a multi-volt (MV) driver (120-to-277V). Ensure that the supply voltage is correct for the driver(s) in this fixture.
6. Reinstall the geartray; insure that no wiring is pinched. Reinstall the lens.



WARNING: These procedures should only be performed by a qualified electrician.

Supply power should be turned off when replacing components or checking connections. Never perform maintenance or cleaning while fixture is energized.

TROUBLESHOOTING TIPS: If the fixture fails to operate properly, check the following:

- ✓ Verify proper line voltage is present.
- ✓ Verify input wiring connections to power source.
- ✓ Verify that the fixture is grounded.

FIG-1

